

**Tools Required:**

3mm hex key

**For use with BEGA floodlights:**



77 680

77 683

**Exchangeable lens accessory installation onto floodlights:**

1. Completely back out and remove existing screws from the cover ring of floodlight. (figure 1).
2. Adjust linear spread lens in secondary trim ring according to desired light distribution.
3. Ensure gasket is positioned correctly.
4. Lead extended screws (provided) through the drilled holes of the primary cover ring to close; (figure 2)
5. Tighten screws evenly and fully to secure.

NOTE: Exchangeable lens with trim ring may be used with other floodlight accessories.  
Exchangeable lens will produce flat beam lighting distribution.

**Figure 1****Figure 2****Accessories**

Please refer to the appropriate accessory installation sheet for further instruction when applicable.

**Distribution:**