

Tools Required:

Standard small screwdriver
3mm hex key



Dimensions

A: 15-1/8"
B: 4"



Weight: 1.5 lbs.

Accessory 70 204:

Material: Earth spike made of UV-resistant glass-fiber reinforced.

Notice to the installer for 70 204 Accessory:

1. For use with floodlight equipped with 1/2" I.P.S. nipple.
2. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Accessory 70 204 - installation:

1. Mount floodlight to earth spike by screwing in 1/2" I.P.S. nipple. Tighten set screw to secure.
2. Push earth spike vertically into soil until stable. If necessary, compact the soil around earth spike to secure.
3. Route wire from floodlight to near by wiring box (See figure 1
4. Make supply wiring and luminaire wiring connections in the octagonal wiring box:

MAIN VOLTAGE SUPPLY WIRE TO BLACK LUMINAIRE WIRE
NEUTRAL (COMMON) SUPPLY WIRE TO WHITE LUMINAIRE WIRE
WIRE GREEN GROUND WIRE TO GREEN LUMINAIRE WIRE

Dimming (if applicable):

DIMMING CONTROL WIRE (+) TO POSITIVE DRIVER DIM CONTROL WIRE
DIMMING CONTROL WIRE (-) TO NEGATIVE DRIVER DIM CONTROL WIRE

Figure 1

