

Tools Required:

Standard small screwdriver



Dimensions

A: 3-1/8 "

B: 1 "



Weight: 1.3 lbs.

Accessory 70 252:

Material: Wood screw made of stainless steel.

Notice to the installer for 70 252 Accessory:

1. For use with floodlight equipped with 1/2" I.P.S. nipple.
2. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Accessory 70 252 - installation:

1. Loosen set screw on the side of wood screw prior to installation.
2. Secure wood screw into mounting surface or tree.

NOTE: Be sure that the mounting surface has sufficient load capacity to support the floodlight and accessory.

3. Mount floodlight to wood screw by screwing in 1/2" I.P.S. nipple. Tighten set screw to secure.
4. Route wire from floodlight down tree into a wiring a box mounted to the base of the tree. Be sure to leave adequate slack in cord to accomodate for future tree growth as needed.

NOTE: Mount an outdoor rated splice box onto or near to base of tree per local code.

5. Make supply wiring and luminaire wiring connections in the octagonal wiring box:

MAIN VOLTAGE SUPPLY WIRE TO BLACK LUMINAIRE WIRE
 NEUTRAL (COMMON) SUPPLY WIRE TO WHITE LUMINAIRE WIRE
 WIRE GREEN GROUND WIRE TO GREEN LUMINAIRE WIRE

Dimming (if applicable):

DIMMING CONTROL WIRE (+) TO POSITIVE DRIVER DIM CONTROL WIRE
 DIMMING CONTROL WIRE (-) TO NEGATIVE DRIVER DIM CONTROL WIRE

NOTE: Leave adequate slack in supply wiring in order to accomodate for future tree growth.