


Tools Required:

Standard small screwdriver

**Dimensions**

A: 5-1/2 "

B: 1-1/8 " - 3-1/8 "

C: 1-1/8 "



Weight: 1.8 lbs.

Accessory 70 280:**Figure 1**

Material: Tube clamp made of aluminum alloy and stainless steel.

Notice to the installer for 70 280 Accessory:

1. For use with floodlight equipped with 1/2" I.P.S. nipple.
2. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Accessory 70 280 - installation:

1. Remove U-bolt from tube clamp by unscrewing two nuts and washers.
2. Attach tube clamp around mounting structure by inserting U-bolt through holes in casting and tighten nuts to secure.

NOTE: Be sure that the mounting structure has sufficient load capacity to support the floodlight and accessory.

3. Mount floodlight to tube clamp by screwing in 1/2" I.P.S. nipple. Tighten set screw to secure.
4. Route wire from floodlight to wiring box.
5. Make supply wiring and luminaire wiring connections in the octagonal wiring box:

MAIN VOLTAGE SUPPLY WIRE TO BLACK LUMINAIRE WIRE
NEUTRAL (COMMON) SUPPLY WIRE TO WHITE LUMINAIRE WIRE
WIRE GREEN GROUND WIRE TO GREEN LUMINAIRE WIRE

Dimming (if applicable):

DIMMING CONTROL WIRE (+) TO POSITIVE DRIVER DIM CONTROL WIRE
DIMMING CONTROL WIRE (-) TO NEGATIVE DRIVER DIM CONTROL WIRE