


Tools Required:

- 2.5mm hex key
- 3mm hex key
- Phillips head screw driver medium

CSA certified to U.S. and Canadian standards.
Suitable for wet locations.



Dimensions

- A: 4"
- B: 3-1/8"




Protection Class: IP65

Weight: 1.3 lbs.

Notice to Installer for 33 506:

- BEGA luminaires may be damaged if connected to conduit systems containing water- Article 300-5G of National Electric Code requires that "Conduits or raceways through which moisture may contact energized live parts shall be sealed or plugged at either or both ends".
- Mounts directly to recessed BEGA 19 538 small opening wiring box (provided).
- See installation sheet 99068 for detailed instructions on 19 538 small wiring box installation. NOTE: Mounting strap not used for this model - luminaire base mounts directly to 19 538 small opening wiring box.
- This luminaire requires a UL listed class 2 remote 24V DC power supply.
NOTE: Be sure to install 19 538 small wiring box with mounting holes oriented in the horizontal position.
- In conformance with U.L. Standards 1598, a silicone-based sealant MUST be used between the mounting plate edge and supporting wall.
- LEDs are high-quality electronic components! Please avoid touching the light output opening of the LED directly during installation.
- Requires a 24V DC class 2 electronic power supply to operate intended LED wattage.

NOTE: Requires a 24V DC class 2 electronic power supply to operate intended LED wattage. (not included). DO NOT USE LINE VOLTAGE



33 506 - installation:

- Loosen 3mm set screw on luminaire outer trim ring and turn ring to the stop (ccw). Remove trim ring with glass from luminaire base.
- Loosen (2) hex screws on LED module plate and CAREFULLY remove LED module - trying not to come into direct contact with the LED chips.
- Route LED wiring through luminaire base and into small opening wiring box for connections to be made.
- Make 24V DC supply wiring and LED connections in small opening wiring box:
NEGATIVE SUPPLY WIRE TO BLACK LED LUMINAIRE WIRE
POSITIVE SUPPLY WIRE TO RED LED LUMINAIRE WIRE
- Attach mounting strap to wiring box using (2) 1/2" screws.
- Attach luminaire base to mounting strap and wiring box by using (2) 1 1/2" 8-32 mounting screws.
- Place a small bead of silicone around the back side of the luminaire base that will come in contact with the finished wall (exterior applications only).
- Replace the LED module carefully along with luminaire lens and trim ring. Turn trim ring to the stop (cw) and tighten outer set screw to secure.

Relamping/Maintenance

No relamping necessary.

Accessories

Please refer to the appropriate accessory installation sheet for further instruction when applicable.

- | | |
|-----------------------|--------|
| Remote 25W LED Driver | 19 580 |
| Remote 50W LED Driver | 19 591 |

Replacement Parts

Description	Part No
Lens	11297311
Lens gasket	831311
LED Driver	75928
LED replacement (3000K)	LED-0238/930
LED replacement (4000K)	LED-0238/940

Lamp: 0.95W LED, 24V DC

In the interest of product improvement, BEGA reserves the right to make technical changes without notice.

Product Safety Warnings:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. SUITABLE FOR WET LOCATIONS.

MIN 90° SUPPLY CONDUCTORS.

CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS.

CONVIENT AUX EMPLACEMENTS MOUILLÉS.

LES FILS D'ALIMENTATION 90°C MIN.
